

INSTALLATION TIPS

LX TUBE CLAMPS

Tools required: 6mm allen wrench – 3mm allen wrench

> Clamps offered in 4 diameters: LXC125 - 1.25" LXC150 - 1.5" LXC175 - 1.75" LXC200 - 2"

When installing the LX Tube clamps:

- 1. Locate mount adapters inside light bar box.
- 2. Remove half-round retainer which holds mounting bolt, this is the only piece utilized for this installment.
 - 3. Locate Allen bolt and nut in clamp package.
- 4. Locate nut inside of clamp package, install into bottom of half-round retainer then slide into trac located on the bottom of the LX LED bar.
- 5. Locate mating half of clamp (the side with thru hole). Utilizing allen head mounting bolt located in the CLAMP package, install washer/lock washer with bolt. With 6mm allen wrench, screw into moon shaped piece, leaving finger tight.
- 6. Position on the vehicle, once clamp is squared up, remove bar & tighten down bolt inside of the clamp (red Loctite recommended). Put light back on vehicle then install second half of clamp, utilizing 3mm allen wrench, install 4 small Allen screws, adjust accordingly, and tighten down.

If you have any questions or comments please feel free to give us a call at 800.624.6234 Or you can fax us at 805.226.8150

THANK YOU FOR CHOOSING Lazer Star Lights!