

INSTALLATION TIPS

LENS REPLACEMENT

**CAUTION: DO NOT TOUCH THE BULB OR INNER REFLECTOR.

Doing so may cause damage to the lamp.

- 1. Slowly unscrew the lens cap in a counter-clockwise direction while at the same time holding the lens down (if yours is still there). This keeps the lens/lamp from twisting in the housing. Be careful not to drop the lens once the cap is removed.
 - 2. Remove the lens gasket (white), lens, and lens O-ring.
- 3. Place the new O-ring in the groove of the cap, if it will not seat then stretch it a little, by taking it out and lightly tugging on it.
 - 4. Place the new lens over the O-ring. Hold it by the edges so as not to get your fingerprints on the inside.
 - 5. Place the new white gasket on the lens.
- 6. Grasp the light body, then screw the lens cover on 1/2 turn. Seat the lamp by pushing the lens all the way down and hold it down. Continue to screw on the lens cover (paying special attention to the white lens gasket, making sure it does not spin or get caught in the threads) while holding the lens down, until tight
- 7. You may want to use some "super glue" and reseal the wire to insure water tightness. Remove any old sealer before applying.

Note: Weekend Concepts cannot be responsible for any lamp or seal damage that may occur during reassembly; this includes any subsequent leaking or failure of any component.

If you have any questions or comments please feel free to give us a call at 800.624.6234 Or you can fax us at 805.226.8150

THANK YOU FOR CHOOSING Lazer Star Lights!